



NOTES:

1. CAST IRON COVER TO BE STAMPED "WATER" FOR WATERLINE VALVES, "REUSE" FOR REUSELINE VALVES, AND "SEWER" FOR FORCEMAIN VALVES
2. INSTALL NON-METALLIC TAPE APPROXIMATELY 24" ABOVE PIPE
3. DEBRIS CAP MUST BE INSTALLED AT TOP OF VALVE BOX.
4. TRENCH ADAPTOR MAY BE INSTALLED IN PLACE OF VALVE BOX AND DEBRIS CAP. SEE SECTION 2660.

TOWN OF BRASELTON WATER & SEWER DEPARTMENTS

JOB TITLE STANDARD DETAIL	SHEET TITLE	DRN. BY: EMI	REV. NO.	BY	DATE
	VALVE BOX	CKD BY:			
		APPD. BY:			
		DATE: MARCH 2004			
		DETAIL No. W-8	FILE No. 03033\W-8.dwg	SCALE: N.T.S.	